

Magee

Pysäköintilaite

Käyttöohje

Table of contents

1. Getting started	35
2. How to use Magee	36
3. Options mode	37
4. Disc mode	38
5. Payment mode	40
6. Device placement	41
7. Battery life and charging	42
8. Service and guarantee	43
9. Care and maintenance	44
10. Approvals and certificates	45
11. CE mark	45
12. WEEE	44
13. Technical data and rights	44

1. Getting started

Thank you for choosing Magee!

Magee is a personal parking device that helps you pay for parking quickly and easily from the comfort of your car. Magee also works as a parking disc that updates and displays your parking time automatically whenever you park.

In this manual, you will find details on how to setup and use your Magee device.

Before reading further, please register the device by following the instructions at <https://magee.witrafi.com/register>.


To register your device, you will need:

- Your Magee device
- The license plate of the vehicle you want to register
- A valid method of payment (for example, a credit card)
- A valid email address

Once online registration is complete, you can start using Magee to pay for parking. No online registration or payment details are required to use the device as a parking disc.

Please note: If you have already registered a Magee device and want to register another one under the same account, you can do so from your account at <https://magee.witrafi.com/login>.

2. How to use Magee



- ① MICRO USB
- ② DISPLAY
- ③ UP BUTTON
- ④ OK BUTTON
- ⑤ DOWN BUTTON

Magee has three buttons: UP, OK, and DOWN. These buttons perform different actions depending on if you press and release them normally, or if you hold them down for an extended period of time (~2 seconds). You can use these buttons to navigate the menus and change device modes as below:

Magee includes three modes of operation: PAYMENT mode, OPTIONS mode, and DISC mode.

	UP button	OK button	DOWN button
Press and release	Move menu cursor up	Confirm / wake device	Move menu cursor down
Hold down (~2seconds)	PAYMENT mode	OPTIONS mode	DISC mode

PAYMENT mode is used to pay for parking. DISC mode is used to operate Magee as an electronic parking disc. OPTIONS mode is used to access additional functions, for example to change the license plate you use to pay for parking if you have multiple vehicles assigned to your device.

3. Options mode

To access OPTIONS mode, hold the OK button until the options menu appears. This will give you access to the following options:

- Sleep: Put Magee to sleep immediately. You can wake Magee at any time by pressing the OK button.
- Choose license: Select a vehicle license plate to use when paying for parking (needed only if you have assigned more

than one license plate to your Magee device). You can assign a new license plate to your Magee device from your account at <https://magee.witrafi.com/login>.

- Language: Choose the preferred language for your Magee device.
- Registration code: Display your Magee device's registration code.
- Update software: Your Magee device will automatically download and install software updates regularly without any action needed from you. Use this option only if you wish to install a new software update manually.

Please note that Magee is connected to the 2G network and the time and calendar of the device is automatically set and updated.

4. Disc mode

To enter DISC mode and use Magee as an electronic parking disc, hold the DOWN button until a parking time is displayed.

Upon entering DISC mode, the device will show the starting time of your parking, rounded to the next half hour, in the centre of the display. The actual

current time will also be displayed in the upper-left corner of the screen.

For example, if you enter DISC mode at 12:35, you will see 12:35 in the upper-left corner and 13:00 in the centre of the display. The vehicle will be considered as parked starting from 13:00, conforming to current legislation on the usage of parking discs.

After some time, the screen will slowly blink on and off to extend battery life.

Before leaving your vehicle, place the device on your vehicle's dashboard so that its screen is clearly visible from the outside through the windscreen.

When you are done parking, simply drive away and Magee will automatically deactivate itself when it senses that you are driving. When Magee senses that you have stopped, it will reactivate itself automatically and update the parking time shown on the screen. You may also press the OK button at any time to wake and restart your parking time.

After 24 hours of continuous parking in DISC mode, Magee will automatically deactivate. You may restart your parking time as stated above.

Please note: Magee can be used as a parking disc only in the municipalities listed at <https://magee.witrafi.com/cities>.

5. Payment mode

When parking in an area that requires payment for parking, hold the UP button until the device enters PAYMENT mode.

The device will connect to the mobile network and display a menu of possible parking areas based on the city you are in. Change the selected parking area with the UP and DOWN buttons if needed, and confirm your selection by pressing the OK button.

As soon as the device has confirmed your payment, it will display the details of your parking event on the screen, including the start time of your parking payment period, the parking area, and the license plate your payment is for.

Please note: Depending on the municipality you are in, you may be required to place the device on your vehicle's dashboard when using PAYMENT mode. For a full list of the municipalities where your Magee device can be used to pay for parking, and for all related information, visit <https://magee.witrafi.com/cities>.

When you are done parking, you must end the parking event either automatically or manually.

To end the parking event automatically, simply start driving. When Magee senses that you are moving, a countdown timer will be displayed on the screen. If you wish to end the parking event, do nothing: when the countdown is over, your parking payment period will stop. If you wish to continue your parking event, you may press the OK button to cancel the countdown timer.

To end the parking event manually, press the OK button and confirm your request to stop parking. Your parking payment period will end immediately.

Please note: Always ensure that your parking event has ended when you are done parking. If your device's battery is low, the device may not be able to end parking for you. In this case, you must plug the device into a power source and end the parking event following the instructions above.

6. Device placement

When using Magee in DISC mode as a parking disc, the device should be placed on the vehicle's dashboard so that its screen is clearly visible from outside of your vehicle through the windscreen.

When using PAYMENT mode, you may be required to place the device on your vehicle's dashboard depending on the municipality you are in. For a full

updated list of the municipalities where your Magee device can be used to pay for parking, and for all related information, visit <https://magee.witrafi.com/cities>.

While driving, it is recommended to keep the device in a stable and secure place that prevents free movement of the device.

7. Battery and charging

The battery charge level of your Magee device is indicated by the battery icon shown in the upper-right corner of the display.

You will be notified with a warning symbol (!) within the battery icon if your battery level becomes low enough that the charge remaining may not last for 24 hours, or if the battery level is too low to use the device.

You may charge Magee at any time by connecting the device to an external power source via a micro-USB charger. When the battery icon displays consistently as full, charging is completed and your device is at its maximum charge level.

Whenever charging, it is recommended to charge your device to its maximum battery level. It is also strongly recommended to continue charging your

device if the battery level indicated includes the warning symbol (!). If your device is unresponsive and does not wake when pressing the OK button, you may need to charge the device to continue use.

Please note: If your device's battery level is too low to use the device, you may need to connect the device to a powered micro-USB charger to stop any on-going paid parking event.

8. Service and guarantee

If you have questions regarding your Magee device or its services, you can find updated information at <https://magee.witrafi.com/faq>. You can also contact our customer service at magee@laatukilpi.fi with any questions or concerns.

Witrafi Oy provides a warranty according to the terms of the Finnish Sale of Goods Act. If faults or issues occur during the guarantee period, the Magee device can be returned to the dealer from which it was bought. The device can then be repaired or replaced. Please also provide a copy of your receipt as evidence of your guarantee.

Do not attempt to open the device under any circumstances, as this might damage the electronics and therefore invalidate the guarantee.

Important Notice

Magee was designed to help make parking as easy, automatic, and hassle-free as possible. However, it is the responsibility of the vehicle's driver to make sure that the Magee device is used and placed properly, including that the parking event start time is correct and displayed appropriately when used as a parking disc, and that the device's battery is adequately charged to cover the full duration of any paid or unpaid parking event. Witrafi Oy will not reimburse any parking charges or fines incurred.

For updated information about the cities where the Magee device can be used, please check <https://magee.witrafi.com/cities>.

9. Care and maintenance

Magee is well adapted to the Finnish climate and can withstand extreme temperatures. Magee has been tested in the temperature range from -25°C to +60°C.

Extended periods of very cold weather (-20°C or less) may negatively affect battery performance and service availability. It is recommended to keep your Magee device continuously connected to an external power source via a micro-USB charger in such temperatures.

Clean your Magee device as necessary with a clean, soft cloth. Never use detergents or other chemicals to clean the device. If your Magee device comes into contact with high levels of humidity or water, wipe it off immediately with a soft cloth.

10. Approvals and certificates

Magee fully complies with the Finnish Communication Ministry's regulation about parking discs and the terms of use for them (12.11.2015/1319 §1 – 4) in compliance with the Finnish Communication Ministry's decision on road traffic law 267/1981 28a § 3.

11. CE mark

Compliance details can be found at <https://magee.witrafi.com/compliance>.

By affixing the CE mark, Witrafi Oy is declaring that its product complies with the general safety regulations from the relevant CE mark directives.

With the CE mark, the manufacturer guarantees that the product has been produced with the safety, health and safety and work and environmental regulations valid across the EU.

12. WEEE

Electric and electronic components (EEE) and materials can be dangerous and toxic to health and the environment and must be disposed properly.

The Magee device must not be disposed of in normal domestic waste: special precautions must be taken. The device can be disposed of via a local recycling centre or by returning it to the point of sale.

13. Technical data and rights

Dimensions: 104 x 65 x 18 mm

Weight: 93 g

Battery rating: 1600 mAh

Charging rating: micro-USB, 2.1A, 5 V

All rights for the Magee product are the property of:

Witrafi Oy

Lönnrotinkatu 32 E

00180 Helsinki

Finland

www.witrafi.com

E-mail: magee@laatukilpi.fi

Content of operating instructions is subject to changes. Check the website <https://magee.witrafi.com/faq> for updated information.

Magee is a personal parking device that helps you pay for parking quickly and easily from the comfort of your car. Magee also works as a parking disc that updates and displays your parking time automatically whenever you park.

Magee fully complies with the Finnish Communication Ministry's regulation about parking discs and the terms of use for them (12.11.2015/1319 §1 – 4) in compliance with the Finnish Communication Ministry's decision on road traffic law 267/1981 28a § 3.

Register your device online:
magee.witrafi.com/register

Magee is a product by Witrafi Oy.
Sales in Finland are handled by LaatuKilpi Oy.